EUROVAC /

BRAKE LATHE DUST EXTRACTION

Eliminate brake lathe dust at the source with a Eurovac Central Vacuum system



- Source capture suction nozzles extracting brake lathe dust at the source
- Dust is extracted via hose and hard ducting back to a Eurovac central vacuum system
- Multiple lathe systems available
- Systems can be used in conjunction with a Euovac "Detailing" vacuum system



- Reduce health risks from harmful airborne brake lathe dust
- Improve the look of your facility with a state of the art brake lathe dust extraction system
- Avoid premature equipment failure due to brake lathe dust ingestion
- Cut down on cleaning costs and increase production



Source capture dust extraction nozzles extracting brake lathe dust back to one of the below Eurovac high vacuum systems.





USA Ph. 800-265-3878